

# Installation Instructions - Ventline Soffit Vents

Models: V2179 / V2184

Soffit Vent	V2179 (3" diameter outlet)	V2184 (4" diameter outlet)
Use With Fan Models	V2270 Series V2280 Series	V2158-00 V2202-00 V2245-00 V2265-00

- 1) Install fan and flex ducting in accordance with fan manufacturer instructions.
- 2) Locate desired location for soffit outlet vent; cut rough opening 1/8" larger than pipe dimension. (3 1/8" for V2179 and 4 1/8" for V2184)
- 3) Pull ducting through rough opening and slide ducting over the outlet pipe of soffit vent and secure the ductwork to the soffit vent with a tie wrap, mechanical fasteners, duct tape rated for use at 200° F., or other method which results in a secure, substantially air tight seal to satisfy HUD Standard section 3280.710(3) and 3280.715(c).
- 4) Push the flex ducting and attached soffit vent back into the rough opening and fasten vent to the soffit with screws, adhesive or other means to acquire a secure attachment.

