




INTERIOR ELECTRICAL SUPPLIES

Interior Refurb



▲ **50059-W**- Self-Contained Rocker Switches
*White finish.
All switches come with snap-on backs.



▲ **50063-W**- Self-Contained Single Switch - White
*Quick hookup connections. All switches come with snap-on backs.



▲ **50064-W**- Self-Contained Receptacles- White



▲ **50050** Ground Fault Circuit Interrupter (GFCI) Receptacle- White



▲ **50059-SW**- Replacement Rocker Switch Only



Back



▲ **50045**- Receptacle Plate Cover with Screw-White Plastic



Back

◀ **50059-P** Snap-on Cover plate only for old **50059** Rocker Switch and **50064-W** receptacle- Back tabs on sides- White



Back

◀ **50059-PW** Snap-on Cover plate only for Wesco Rocker Switch- Back tabs on top and bottom- White



▲ **50041** Single Switch (works with **50040** plate)- White



▲ **50046** Double Receptacle (works with **50045** plate) - White



▲ **50059-DBLW** Replacement Snap-on Double Cover Plate only for Rocker Switch- White

For rangehoods, see page 29.
For exterior electric fixtures, see page 64.



Back

◀ **50063-PW** Snap-On Plate Only for Self-Contained Single Switch- *Snap tabs on back are on the sides.



◀ **50040**- Single Switch Plate with Screws- White Plastic



▲ **50062**- "Dog-Ear" Pawl for Self-Contained Switch/Receptacle

